Wind Sign II & Wind Sign Deluxe



www.plasticade.com

Snap Frame Assembly Instructions

Hardware Provided



Snap Frame Base

Spring Assembly

- 1. Lay frame on its side and base on end as shown
- 2. Place washer on bolt fastener
- 3. Insert bolt fastener through hole in bottom of base
- 4. Align spring assembly with bolt fastener
- 5. Screw bolt fastener into bottom of corresponding spring assembly, tighten
- 6. Repeat for second bolt fastener, washer, and spring assembly
- 7. Turn sign frame upright, with base flat on the ground (The Allen Wrench is not needed for the assembly of the Snap Frame)

Sign Insertion Instructions





1. Snap open all four side rails*




See Reverse Side for

"Quick-Change"™

Frame Instructions

2. Remove Clear Protective Cover from frame



inserting poster corners into the four corner slots

PINCH POINT

KEEP HANDS CLEAR



3. Place poster in frame, 4. Place clear protective




poster cover in frame, inserting cover corners into the four corner slots



WARNING: Use caution when you snap rails open and close


To move sign stand from place to place - grab frame, tilt stand back on wheels, and push sign to move it




CAUTION: Sign Substrate should weigh no more than 5 lbs. per side.



Unscrew cap from fill hole and pour dry sand into base. 115 lbs. of sand is recommended. Sand should be level inside of base to maintain optimum balance. Shake gently to level sand.




Sign Insertion Instructions



 Slide sign down through the stay tabs™



Unscrew cap from fill hole and pour dry sand into base.



 Slide through, pulling sign in front of bottom slot until sign hits the base

Fill with up to 115 lbs. of sand to achieve desired wind resistance. Sand should be level inside of base to maintain optimum balance. Shake gently to level sand. Wind Sign Deluxe Wind Sign II

"Quick-Change" Frame

Pounds of

Ballast

70 lbs.

100 lbs.

115 lbs.

Head-on

Wind

Resistance

40 mph

55 mph

60 mph

	0	
Wind Sig	n Deluxe	
"Quick-Cha	nge" Frame	
	Head-on	

Quick-Change" Frame	
Pounds of Ballast	Head-on Wind
	Resistance
70 lbs.	40 mph
100 lbs.	45 mph
115 lbs.	50 mph



CAUTION: Sign Substrate should weigh

no more than 5 lbs. per side.

 Push sign up into top slot





4. Slide sign down into bottom slot

To move sign stand from place to place - grab handle, tilt stand back on wheels, and push sign to move it